



WILD FROG DEW GTF

M3x8mm AND M3x10mm SCREWS

TOP PLATE

20mm STANDOFF

CENTER PLATE

SIDE PLATE

TPU MOUNT OF CAMERA CAGE

INTERLOCK PLATE

BOTTOM PLATE

M3x6mm SCREW

M3x12mm SCREW

M3x14mm SCREW

STEP 1

CONNECT INTERLOCK PLATE WITH CENTER PLATE USING M3x6mm SCREWS

STEP 2

SLIDE ARMS INTO INTERLOCK PLATE AND COVER THEM WITH BOTTOM PLATE
USE M3x12mm SCREWS FOR PRESSNUTS AND M3x14mm FOR STANDOFFS

STEP 3

ASSEMBLE CAMERA CAGE USING TPU MOUNT AND SIDE PLATES
INSTALL CAGE IN DEDICATED HOLES IN CENTER PLATE

STEP 4

ATTACH TOP PLATE USING M3x8mm AND M3x10mm SCREWS AND LOCK CAMERA CAGE
TIP: USE M3x10mm TO INSTALL OPTIONAL 3D TPU PRINTS, E.G. FIN

